



**TIPS FOR CLEANING
YOUR DISHWASHER**

1. DRAINING THE MACHINE

After usage, allow the machine to drain completely so all dirty water is removed.

Press and hold the button for approximately 3 seconds. In the newer displays, the machine indicates that draining has started.

The older displays just provide a colour signal on the button.

The machine switches off automatically after being drained.





CLEANING THE MACHINE

2. REMOVE RACK AND RACK CARRIER

Front-loading & glasswashers:

Go to step 3

Hood-type dishwashers:

Lift up the rack carrier and remove it.



3. REMOVE WASH AND RINSE ARMS

Removal:

Press and hold down the blue buttons on the rinse arm. It can then be removed.

On older machines the arms are fixed with a screw. Loosen this screw and the arms can be removed.

Don't forget the upper wash and rinse arms.

Cleaning:

Rinse the arms thoroughly with running water. Make sure that none of the spray nozzles are clogged.



4. REMOVE STRAINER

Remove the blue strainer and the large strainer at the bottom of the wash chamber. Clean both strainers under running water so that there are no longer any soil residues.

Check the quality and condition of the strainer. Make sure that they are neither bent nor torn.



5. CLEANING THE BOTTOM OF THE WASH TANK

Clean the bottom of the wash tank on the underside of the machine. There may be food residues here.



6. POSITION TANK STRAINER & MOUNT RINSE ARM

Re-insert the cleaned strainers, along with the wash and rinse arms.

Pay attention to the arrows when inserting the blue strainer. The arrow on the blue strainer must match the arrow on the stainless steel strainer. If these don't match, the control system issues an error message during the next start-up.



7. LEAVE THE MACHINE OPEN

There is moisture on the inside of the machine due to residual water.

To allow air circulation, leave the door or hood of the machine open even when it is at a standstill.

This also avoids unpleasant odours developing.

